

# Three simple steps to comply with SCAQMD Rule 1466

Rule 1466 applies to earth-moving activities of soil with applicable toxic air contaminants. The purpose of the rule is to minimize off-site fugitive dust emissions by establishing air monitoring and dust control measures.

Here are three simple steps to comply with Rule 1466.

## 1 General Notifications

Install SCAQMD approved signs along the property line. Notify SCAQMD before commencing activities and when an exceedance occurs. Maintain accurate recordkeeping and reporting.

## 2 Air Monitoring

PM<sub>10</sub>, plus wind speed and direction must be monitored in real-time. Place a minimum of one upwind and one downwind monitor close to the property line. Choose from the list of **Executive Office pre-approved PM<sub>10</sub> monitors**, such as the Aeroqual Dust Sentry.

## 3 Dust Control Measures

Install 6-foot fencing/windscreen and apply dust suppressant methods, such as wetting and removing any track-out dust from vehicles and tires. Cover and label contaminated stockpiles. Cover and label contaminated stockpiles.

